	FIG	Wire & Cable	Termination Instructions	T-111176	
		of the Angelus Corporation	Approved : PFT	Date : 03/11/21	
		Fax (262) 246-0450 www.picwire.com ingdale Road, Waukesha, WI 53186	Distribution : USER	Rev 0 Uncontrolled if Printed	
	Terminatio	on Instructions for PIC P/N 111176 - I (for E6A5826 & E74826 E7	RJ45 PLUG WITH PROTECTIVE BC	ЮТ	
	_				
	Required Tooling : Recommended Hand Tools :	PIC P/N 111183 Crimp Tool, Heat Gun ols : X-acto Knife, Sharp Razor, Wire Cutters, Magnifier, Small Side Snips			
	Recommended Hand Tools :	Tagnifier, Small Side Snips			
			All Dimensions in inc Figure 1	ches - Not to Scale	
1)		tall the 3/8" long piece of 8/2 ATUM, then ins toward the end of cable. Shrink the 1" long p in the end of the cable (Fig. 1).	iece of	0.070	
2)		nd of the cable, through the jacket only. DO N jacket, and roll the braids back over the jacket		→ 0.970" ← T A →> .675" ←	
3)	Remove the foil shields around each pair at Cut A to expose the twisted pairs (Fig. 3). Verify insulation integrity.		(Fig. 3).		
4)	Carefully straighten each wire. Align wires into desired wire configuration per work print, and install wires into the load bar. Use installed load bar to "comb" or work the wires into shape, until thoroughly straight for approximately half the cut length. Set far edge of load bar at .620" and trim conductors flush (Fig. 4).		he wires into Figure 3	trim foil shields	
5)	the connector body, keeping alig the connector past Cut A, while their channels. Proper insertion	tab down, to allow entry for wires. Install wire nument intact. To complete full insertion, push lightly wiggling the cable to help the conducto is indicated by viewing ALL of the wire condu- nector body. Use Magnifier if needed (Fig. 5).	cable into rs slide into Figure 4	trim wire flus	
5)	Bend the strain relief tab to align enclosed (Fig. 6). Lightly bend		→ .620" ←		
7)		ping the connector. Crimp using PIC P/N 1111 the end of the crimped strain relief tab (Fig 7)		Figure 5 Conductors should be visible and fully insert	
8)	Slide the boot up over the crimp at the base to lock it in place (Fi	ed strain relief tabs until fully seated. Shrink 8 g. 8).	3/2 ATUM		
	Figure 6 braids fully enclosed	Figure 7 trim excess brai	ids Figure 8 s	ilide boot up over connector	
			shrink 8/2 A	ATUM at base.	
		RI45 Wiring Configuration for 568A or 568B	568A Configuration 568B Configuration White / Green White / Orange Green Orange White / Orange White / Green Blue Blue White / Blue White / Blue		
		Top View 7	Orange Green White / Brown White / Brown Brown Brown		